

Maintenance Guide

Product Range:**Powder coated aluminium corner protection profiles****Material:**

Aluminium Alloy 6063 T6

General:

Immediately after installation and the removal of protective tape, the corner protection profile should be wiped with a dry, soft cloth to remove any handling marks and fingerprints.

Our powder coated aluminium corner protection profiles are produced to Qualicoat standard specification. For RAL colour availability and suitability on individual profiles always contact our Sales Team.

The installed profile should be wiped clean on a daily basis to avoid build up of dust and dirt which may make it more difficult to maintain its appearance.

Our powder coated corner protection profiles are suitable for installations in areas with low to medium traffic volumes. Heavy traffic and continuous impact damage can wear through the finish to reveal the natural aluminium colour beneath.

Cleaning**Powder Coat Finish:**

Wipe clean with a mild detergent, diluted with water, on a damp, not wet, cloth. Do not use abrasive pads as these may scratch the surface.

Sponge the soiled area with the solution, then rinse with clean water and dry.

Prolonged exposure to damp environments, acids or strong alkali solutions may lead to corrosion of the metal.

Important:

**Ensure that all surfaces are wiped dry after cleaning.
Care must be taken to protect surrounding wall coverings and finishes during maintenance.**

Made with Precision, Finished with Care

CAT Flooring Accessories, Units 24 A,B,C, Park Avenue Estate, Luton, Bedfordshire LU3 3BP, U.K.

T: +44 (0) 1582 561 500

email: sales@catflooringaccessories.com

website: www.catflooringaccessories.com